



Safety and Security	Golf Golf Wagon	Golf Life Golf Wagon Life	Golf R-Line	Golf GTI
Airbags				
Driver and front passenger airbags	S		S	S
Driver and front passenger side airbags	S	S	S	S
Front centre airbag	S	S		
Rear seat side airbags	S	S	S	S
Curtain airbags, front and rear	S	<u> </u>	S	S
Anti-theft				
Alarm system with interior monitoring and towing protection				S
Electronic engine immobiliser	<u>S</u>	S	<u> </u>	<u> </u>
Body				
Fully galvanised body with 12 year corrosion perforation warranty	<u>S</u>	<u>S</u>	<u>S</u>	<u>S</u>
Door side impact protection	<u>S</u>	<u></u>	<u>S</u>	
Rigid safety cell with front and rear crumple zones	<u>S</u>			
Brakes Automatic flashing brake lights activated in emergency braking situation				
Anti-lock Braking System (ABS)	<u> </u>	<u> </u>	<u> </u>	<u> </u>
Auto hold function				<u>s</u>
Brake Assist	S		S	<u>s</u>
Electronic Brake-pressure Distribution (EBD)	S	<u></u> S	<u></u>	<u> </u>
Electro-mechanical parking brake	S			
Hill Start Assist (HSA)	S	S	S	_
Multi-collision brake	S	S	S	S
Red brake callipers	=			<u></u>
Child restraints				
Child seat top tether anchorage points (3)	S	S	S	S
ISOFIX child seat anchorage points, outer rear seats	<u>S</u>		S	<u> </u>
Head restraints				
Front safety optimised head restraints, height adjustable	S	S		
Integrated front head restraints			S	S
Rear head restraints height adjustable (3)	<u></u>	S	S	S
IQ.DRIVE*				
Adaptive Cruise Control (ACC) with stop and go function	<u>S</u>		<u> </u>	<u> </u>
Automatic kerb function when reversing, passenger's side exterior mirror tilt	<u>S</u>	<u></u>	<u>S</u>	<u></u>
Side Assist with Rear Traffic Alert	<u>S</u>	<u>S</u>	<u>S</u>	<u></u>
Distance warning display	<u>S</u>	<u>S</u>	<u> </u>	<u>S</u>
Driver Fatigue Detection system	<u></u>	<u> </u>		<u>S</u>
Emergency Assist		<u>S</u>	<u>S</u>	<u> </u>
Exit Warning System Front Assist with Pedestrian and Cyclist Monitoring functions		<u></u>	<u>S</u>	<u>S</u>
Lane Assist, lane departure warning system	<u></u>	<u>s</u>	<u>s</u>	<u>S</u>
Light Assist, automatic high beam headlight function			<u>S</u>	<u>S</u>
Manoeuvre braking, low speed emergency braking front and rear	S		<u></u>	<u>S</u>
Oncoming vehicle braking when turning	<u></u>	<u></u>	<u>s</u>	<u>s</u>
Optical Parking System (OPS) in infotainment display	<u></u>	<u>s</u>	<u>s</u>	<u>s</u>
Park Assist, parking bay and parallel parking assistance	<u></u>	<u>S</u>	<u></u>	<u> </u>
Parking distance sensors, front and rear with acoustic and visual warning	S	<u>s</u>	<u>S</u>	<u> </u>
Rear View Camera (RVC) with dynamic and static guidance lines	S	<u>S</u>	<u>s</u>	S
Traffic Jam Assist	S	<u> </u>	S	S
Travel Assist	S	S	S	S

<sup>\*</sup>Safety technologies are designed to assist the driver, but should not be used as a substitute for safe driving practices.

Safety and Security Cont.	Golf Golf Wagon	Golf Life Golf Wagon Life	Golf R-Line	Golf GTI
Locking				
Child safety locks on rear doors	S	S	S	S
Fuel filler flap lock/unlock by remote, push to open	S	S	S	S
Keyless Access, keyless entry and starting system including starter button		S	S	S
Keyless Go, keyless starting system including starter button	S	_	_	_
One touch lock / unlock for driver	S	S	S	S
Programmable locking functions	S	S	S	S
Remote central locking	S	S	S	S
Seat Belts				
Front height adjustable with pre-tensioners and belt force limiters	S	S	S	S
Proactive occupant protection system in combination with Front Assist and Side Assist	S	S	S	S
Outer rear with belt tensioner and force limiter	S	S	S	S
Visual and acoustic warning for front and rear seat passengers seat belts not fastened	S	S	S	S
3 point seat belts for all passengers	S	S	S	S
Traction Control				
Anti-Slip Regulation (ASR)	S	S	S	S
Electronic Differential Lock (EDL)	S	S	S	S
Electronic Stabilisation Program (ESP)	S	S	S	S
Extended Electronic Differential Lock (XDL)	S	S	S	S
Vehicle Dynamics Manager, coordinates and activates the functions:				
Adaptive Chassis Control	_	_	_	S
Extended Electronic Differential Lock (XDL)	S	S	S	S
Front differential lock				S
Warning Triangle	S	S	S	S

Exterior Equipment and Styling	Golf Golf Wagon	Golf Life Golf Wagon L	Golf R-Line	Golf GTI
Exterior highlights				
Body coloured bumper bars and door handles	S	S	S	S
Body coloured exterior rear view mirrors	S	S	S	S
Exposed chrome exhaust tail pipes, left and right				S
Large lower air intake with black honeycomb insert				S
Lower front spoiler extensions and front bumper detail in black				S
Lower body side sill panel extensions in black finish				S
Lower body side sill panel extensions in gloss black			S	
Radiator grille highlights in gloss black and chrome	S	S	S	
Radiator grille with red/illuminated strip and GTI nameplate				S
Rear bumper with black diffuser	S	S		
Rear bumper with black sports diffuser				S
Rear roof spoiler with black aerodynamic extensions				S
R-Line front bumper with gloss black C signature, front spoiler and large lower air intake			S	
R-Line rear bumper with gloss black sports diffuser and chrome trim			S	
Roof rails, black Golf Wagon	S			
Roof rails, chrome Golf Wagon	_	S		
Trapezoidal chrome bumper trims, left and right			<u>S</u>	
Paint				
Gloss paint finish	S	S	S	S
Metallic / Pearl Effect paint finish	0	0	0	S
Premium Gloss paint finish			0	S
Premium Metallic paint finish	0	0	0	0









Exterior Equipment and Styling Cont.	Golf Golf Wagon	Golf Life Golf Wagon Life	Golf R-Line	Golf GTI
Exterior Lighting				
Coming / leaving home function	<u>S</u>	<u>S</u>	<u>S</u>	
Fog lamp, rear	S			
Front fog lights with cornering light, 5x LED mounted each side in lower bumper in an X	_	_	_	S
formation				
Illuminated door handle recesses		<u> </u>	<u> </u>	S
Illuminated LED strip on radiator grille				S
LED headlights for low and high beam with LED daytime driving lights	S	S		
LED performance headlights for low and high beam with unique LED daytime driving light	_	_	S	S
signature and automatic self-levelling				
LED rear tail lights	<u> </u>	S	S	S
Low light sensor with automatic headlight function	<u> </u>	S	<u> </u>	<u> </u>
Poor weather light and cornering light			S	<u> </u>
Rear registration plate light, LED	S	S	S	S
Surround lighting with welcome light (projection from door mirror)		<u> </u>	S	<u> </u>
Tinted Glass				
Heat insulating tinted glass	S	S	S	S
Dark tinted rear side window and rear window glass, 65% light absorbing			S	S
Tinted rear tail light clusters	S	S	S	S
Wheels				
Alloy wheels (Norfolk) 16x7" with 205/55 R16 tyres	S			
Alloy wheels (Ventura) 17x7½" with 225/45 R17 tyres		S		
Alloy wheels (Bergamo) 18x7½" with 225/40 R18 tyres			S	
Alloy wheels (Richmond) 18x7½" with 225/40 R18 tyres				S
Anti-theft wheel bolts	S	S	S	S
Low tyre pressure indicator	S	S	S	S
Weight and space saving spare wheel	S	<u> </u>	S	S

Comfort and Convenience	Golf Golf Wagon	Golf Life Golf Wagon Life	Golf R-Line	Golf GTI
Armrest				
Front centre armrest, height and longitudinally adjustable with storage box and rear air outlets (2)	S	S	S	S
Rear seat centre armrest with cup holders (2) and load through provision Golf	_	S	S	S
Rear seat centre armrest with cup holders (2) and load through provision Golf Wagon	S	S		
Air conditioning				
3 zone automatic climate control air conditioning with Smart and Classic Climate menus	S	S	S	S
Air Care air cleaning function	S	S	S	S
Air quality and humidity sensor with automatic air recirculation	S	S	S	<u> </u>
Dust and pollen filter	S	S	S	<u> </u>
Touch slider temperature controls		<u> </u>	<u> </u>	<u> </u>
Comfort indicator function (1 x touch = 3 x flash)	<u></u>	<u></u> S	<u></u>	<u></u>
Cup Holder				
Front (2)	S	S	S	S
Rear (2)		S	S	S
Bottle holders in front door pockets	S	S	S	S

Comfort and Convenience	Golf Golf Wagon	Golf Life Golf Wagon Life	Golf R-Line	Golf GTI
Driving profile selection - Eco, Comfort, Sport and Individual driving modes			S	S
Floor mats Front and rear, carpet		s	S	S
Grab handles - Soft fold away grab handles, front and rear	S	S	S	S
Interior highlights Aluminium finish accelerator and brake pedals			<u> </u>	
Black headlining and pillar trim				
Chrome highlight trim on air vents, power window and exterior mirror switches		S	S	S
Decorative inlays, "new look" to dashboard and front doors	S			
Decorative inlays, "nature crossed brushed" to dashboard and front doors		S		
Decorative inlays, "carbon grey" to dashboard and front doors			S	
Decorative inlays, "black metal chrome" to dashboard and front doors				S
Interior lighting				
With time delay	S	S	S	S
LED front reading lights (2) and rear passenger reading lights (2)	<u> </u>	S	S	<u>       S                             </u>
_10 colour LED ambient lighting		S		
30 colour LED ambient lighting		P	<u> </u>	<u> </u>
Driver and front passenger LED foot well lighting, selectable light colour		P	<u> </u>	<u> </u>



S Standard

Comfort and Convenience Cont.	Golf Golf Wagon	Golf Life Golf Wagon Life	Golf R-Line	Golf GTI	
In car entertainment and technology					
Digital Cockpit Colour digital display with customisable views of speedometer, tachometer, driving data and driver assistance systems	S	_	_	_	
Composition Media audio system 8.25" colour capacitive touch screen display with smartphone style HMI, AM/FM radio, telephone, media, App-Connect, sound, vehicle and driver assistance system settings	S 	_	_	_	
Innovision Cockpit <u>Digital Cockpit Pro</u> Colour digital display with multiple customisable views of speedometer, tachometer, navigation, driving data, audio, telephone and driver assistance systems	_	S	S	S	
<u>Discover Pro audio and satellite navigation system</u> 10.0" colour capacitive touch screen display with smartphone style HMI, customisable home screen, proximity sensor, gesture and voice control, AM/FM radio, navigation map views, telephone, media, App-Connect, sound, background lighting, vehicle and driver assistance system settings	_	\$	S	S	
App-Connect USB interfaces for Apple CarPlay® and Android Auto™ in front centre console	S	S	S	S	
Wireless App-Connect for Apple CarPlay® and Android Auto™			<u>S</u>	<u>S</u>	
Inductive wireless charging  2 USB-C ports in the front, 2 USB-C charging sockets on the centre console in the rear	<u> </u>	<u>S</u>	<u>S</u>	<u>S</u>	
Audio, voice, driver assistance system and Digital Cockpit control buttons mounted on steering wheel	S	_ <del></del> S			
Audio, voice, driver assistance system and Digital Cockpit touch controls mounted on sports steering wheel	$\equiv$	_	S	S	
Bluetooth® phone connectivity, operation via touch screen infotainment system or Digital Cockpit and Bluetooth® audio streaming	S	S	S	S	
DAB+ Digital radio reception	S	S	S	S	
Speakers, front and rear (6)	S				
Speakers, front and rear (6) plus centre speaker		S	S	<u> </u>	
Luggage compartment					
Electrically operated automatic opening and closing of the tailgate with Easy Open and Easy Close functions Golf Wagon	_	S	_	_	
Load restraining hooks	S	S	S	S	
Luggage compartment light	S	S	S	S	
Luggage cover, removable Golf	<u>S</u>	<u>S</u>	<u> </u>	<u> </u>	
Luggage cover, extendable with automatic (2 stage) opening Golf Wagon	<u>S</u>	<u>S</u>			
Luggage net partition, extendable rear seat backrest to roof lining Golf Wagon  Shopping bag hooks	<u>S</u>	<u>S</u>			
Storage compartments in side lining	<u>S</u>	<u>S</u>	<u>S</u>	<u>s</u>	
Variable luggage compartment floor level Golf	<u>S</u>	<u>s</u>	<u>s</u>	<u> </u>	
12 volt socket		S	S	<u>S</u>	
Mirrors					
Automatic dimming interior rear-view mirror				<u> </u>	
Electrically heated and adjustable exterior mirrors	S	S	S	S	
Electrically foldable exterior mirrors		S	S	S	
LED turn indicators integrated in exterior mirrors	S	S	S	S	
Power steering					
Electro-mechanical, vehicle speed and steering input sensitive	S	S	S	S	
Progressive steering					
Sunroof					
Panoramic glass sunroof, electrically slide and tilt adjustable (front half section Golf Wagon) with integrated wind deflector and sunblind		P ——	0	P	

Comfort and Convenience Cont.	Golf Golf Wagon	Golf Life Golf Wagon	Golf R-Line	Golf GT1
12V socket				
Centre console	S	S		
Luggage compartment	_	S	S	S
Seating				
Standard front seats	S			
Comfort front seats		S		
Sport front seats			<u>S</u>	<u> </u>
Height adjustment for front seats	S	<u>S</u>	<u>S</u>	<u> </u>
Lumbar adjustment for front seats, manually adjustable		<u>S</u>	S	<u> </u>
Rear seat backrest with remote release Golf Wagon	<u>S</u>	<u>S</u>		
Split folding rear seat backrest (40/60)	<u>       S                             </u>	<u> </u>	S	
Steering wheel				
3 spoke leather covered steering wheel	S	S		
3 spoke leather covered sports steering wheel			S	<u> </u>
Audio, driver assistance and Digital Cockpit controls	S	S	S	S
Gearshift paddles	S	S	S	S
Height and reach adjustable steering wheel	<u> </u>	<u> </u>	S	<u> </u>
Storage				
Centre console storage compartment under armrest	S	S	S	S
Compartment in dashboard centre console	S	S	S	S
Glove compartment with illumination	<u> </u>	<u> </u>	<u>       S                             </u>	<u>       S                             </u>
Front door pockets with bottle holders, lined	<u> </u>	<u>      S                              </u>	<u>       S                             </u>	<u>       S                             </u>
Front seat backrest storage pockets		S	S	<u> </u>
Net on front passenger side centre console	<u>S</u>	<u>S</u>		<u>S</u>
Rear door pockets, lined	<u> </u>	<u> </u>	<u> </u>	
Transmission				
Gearshift recommendation indicator	S	S	S	S
7 speed Direct Shift Gearbox (DSG)				S
8 speed automatic transmission with sport mode	<u>      S                              </u>	<u> </u>	<u> </u>	
Upholstery				
Cloth seats	S			
Comfort cloth seats		S		
Sport cloth and microfleece seats			S	
Vanity Mirrors				
Driver's and passenger's side vanity mirrors in sun visor	<u>       S                             </u>	S	S	<u>       S                             </u>
Illuminated on driver's and passenger's side	<u> </u>	<u> </u>	<u> </u>	<u> </u>
Windows				
Power front and rear, with roll-back function and one-touch up-down	<u> </u>	S	S	S
Remote operated convenience close and open feature (programmable)				
Wipers				
2 speed aero windscreen wipers with wash/wipe	<u>S</u>	<u>S</u>	<u>S</u>	_5
Rain sensor	<u>S</u>	<u>S</u>	_5_	_5
Rear window with wash/wipe and intermittent wipe		_5_		5



Options	Golf Golf Wagon	Golf Life Golf Wagon L	Golf R-Line	Golf GTI
Sound & Vision package				
Harman Kardon 480W premium audio system with 8 speakers plus centre speaker, subwoofer and 12-channel amplifier Head up display, windscreen projection - display of speed, driver assistance systems and navigation turn by turn direction		0	0	
Sound & Style package				
Alloy wheels (Adelaide) 19x8" with 235/35 R19 tyres Harman Kardon 480W premium audio system with 8 speakers plus centre speaker, subwoofer and 12-channel amplifier Head up display, windscreen projection - display of speed, driver assistance systems and navigation turn by turn direction		_	_	0
Comfort & Style Package				
30 colour LED ambient lighting including front passenger foot wells Comfort sport front seats Microfleece and cloth seat upholstery Panoramic glass sunroof, electrically slide and tilt adjustable (front half section Golf Wagon) with integrated wind deflector and sunblind	_	0	_	_
Luxury package				
Active climate seats in front, heated and ventilated  Electric adjustment for driver's seat with 3 position memory and convenience function  Lumbar adjustment for driver's seat, electrically adjustable  Memory function for exterior mirrors  Panoramic glass sunroof, electrically slide and tilt adjustable with integrated wind deflector and sunblind  Vienna leather appointed seat upholstery with red decorative stitching  Leather appointed seats has a combination of require and artificial leather, but are not wholly leather.	_	-	-	0



Leather appointed seats has a combination of genuine and artificial leather, but are not wholly leather







## Golf, Golf Wagon, Golf Life, Golf Life Wagon & Golf R-Line - Colours and Upholstery



**Pure White** 



Deep Black PE



Dolphin Grey M



Reflex Silver M (Excluding R-Line)



Atlantic Blue M



Pomelo Yellow PM



Moonstone Grey P (R-Line)



Golf, Golf Wagon Standard Seats Cloth



Golf Life, Golf Wagon Life **Comfort Seats** Comfort cloth



Golf Life, Golf Wagon Life Comfort sport seats (Optional) Microfleece-cloth



Golf R-Line Sports cloth-Microfleece

Please note: Premium (P), Metallic (M), Premium Metallic (PM) and Pearl Effect (PE) paint are optional at additional cost, except GTI. Premium Metallic (PM) paint is optional at additional cost GTI. The print process does not allow for exact reproduction of the exterior or the upholstery colours. Please contact your Volkswagen Dealer for further information on colours and upholstery combinations.

## **Golf GTI - Colours and Upholstery**







Deep Black PE



Dolphin Grey M



Moonstone Grey P



Atlantic Blue M



Kings Red PM



'Scale Paper' Black/Red Sports cloth seat upholstery



**Black Vienna** Leather appointed seat upholstery#

#Leather appointed seats have a combination of genuine and artificial leather, but are not wholly leather.

Please note: Premium (P), Metallic (M), Premium Metallic (PM) and Pearl Effect (PE) paint are optional at additional cost, except GTI. Premium Metallic (PM) paint is optional at additional cost GTI. The print process does not allow for exact reproduction of the exterior or the upholstery colours. Please contact your Volkswagen Dealer for further information on colours and upholstery combinations.

## **Technical Specifications**

	Golf Life / Golf Wagon Life Golf R-Line	Golf GTI
Engine	1.4 litre TSI	2.0 litre TSI
Туре	4 cylinder inline turbocharged direct injection petrol with engine Start/Stop system and brake energy recuperation.*	4 cylinder inline turbocharged direct injection petrol with engine Start/Stop system and brake energy recuperation.*
Installation	Front transverse	Front transverse
Cubic capacity, litres/cc	1.4/1395	
Max power, kW @ rpm	110 @ 5000	180 @ 5000 - 6200
Max torque, Nm @ rpm	250 @ 1500 - 4000	370 @ 1600 - 4300
Emission level~	EU6	EU6
Fuel type (Recommended)	Premium unleaded 95 RON minimum	Premium unleaded 95 RON minimum
<b>Transmission</b> Driven wheels	<b>8 Speed Automatic</b> Front wheel drive	7 Speed Direct Shift Gearbox (DSG) with sport mode Front wheel drive
Performance 0 - 100 km/h, seconds	8.5 (8.8)	6.4
Fuel Consumption **		
Combined, L/100km	5.8 (5.9)	7.0
Urban, L/100km	7.2 (7.3)	9.3
Extra Urban, L/100km	5.0 (5.1)	5.6
CO <sub>2</sub> emission g/km~	132 (135)	
Fuel tank capacity litres	50	50
Weight		
Tare Mass kg's	1304 (1371)	
Towbar Capacity, braked≠ kg	1500	1600
Towbar Capacity, unbraked≠ kg	660 (690)	
Towbar Load Limit≠ kg	80	80
Suspension		
Front Axle	Independent, MacPherson struts with lower A-arms. Anti-roll bar. Lowered sports suspension R-Line.	Independent, MacPherson struts with lower A-arms. Anti-roll bar. Lowered sports suspension with Adaptive Chassis Control.
Rear Axle	Independent, four-link with coil springs. Anti-roll bar. Lowered sports suspension R-Line.	Independent, four-link with coil springs. Anti-roll bar. Lowered sports suspension with Adaptive Chassis Control.
Steering	Electro-mechanical power assisted rack & pinion steering. Progressive steering R-Line.	Electro-mechanical power assisted rack & pinion steering. Progressive steering.
Turning Circle (m)	10.9 (11.05)	10.9
Brakes		
Front	Ventilated discs	Ventilated discs
Rear	Discs	Discs
Brake Systems	Anti-lock Braking System (ABS) with Electronic Brake-pressure Distribution (EBD), Brake Assist and Electronic Stabilisation Program (ESP).	Anti-lock Braking System (ABS) with Electronic Brake-pressure Distribution (EBD), Brake Assist and Electronic Stabilisation Program (ESP).

Golf / Golf Wagon

(Specific Golf Wagon and Golf Wagon Life figures in brackets).

<sup>~</sup>Emission level according to European Regulation (EC) No. 715/2007 and Regulation (EC) No. 692/2008, UN ECE R83/06 and later amendments.

<sup>\*</sup>The Start/Stop system is designed to reduce fuel consumption and CO2 emissions. It achieves this by automatically switching off the engine while the vehicle is stationary and then starting it again automatically when the driver wants to drive off. There are certain operating conditions where the Start/Stop system is deactivated (e.g. during engine warm-up), please refer to the owner's manual for full operating information.

<sup>#</sup> Please note towbar capacities are applicable to the Genuine Volkswagen Accessory towbar. Volkswagen Group Australia does not endorse or will not be held liable for any claim, loss or damage arising from the use or fitment of electronic trailer brakes.

<sup>\*\*</sup>Fuel consumption figures according to ADR 81/02 derived from laboratory testing. Factors including but not limited to driving style, road and traffic conditions, environmental influences, vehicle condition and accessories fitted, will in practice in the real world lead to figures which generally differ from those advertised. Advertised figures are meant for comparison amongst vehicles only.

## **Technical Specifications**

	Golf Life	Golf Wagon Golf Wagon Life olf R-Line	Golf GTI
Exterior Dimensions			
Overall length mm	4;	284 (4633)	4287
Width mm		1789	1789
Height mm	14	456 (1483)	1463
Wheelbase mm	2636 (2686)		2631
	Golf / Golf Wagon	Golf Life / Golf Wagon Life / R-Line	Golf GTI
Track, front mm	1539	1533 (1539)	1535
Track, rear mm	1509	1503 (1509)	1513
Luggage area volume			
Rear seat upright L		374 (611)	374
Rear seat folded L	1:	230 (1642)	1230
Length, rear seat upright mm	8	00 (1062)	787
Length, rear seat folded mm	14	493 (1845)	1545
Width between wheel arches mm		1003	1003



13 Running Headline Technical Specifications | 13



## **Glossary**

#### Adaptive Cruise Control (ACC)

Adaptive Cruise Control (ACC) is an extension of the conventional cruise control system with advanced capabilities based on a radar sensor. When ACC is activated, the vehicle automatically brakes and accelerates to a speed and distance set by the driver.

If the Golf approaches a slower vehicle, the ACC brakes the car to the same speed and maintains the preselected distance. Even when a vehicle pulls into the same lane in front of you or slows, your vehicle is automatically decelerated to the pre-selected distance. If the vehicle ahead moves out of your lane, the Golf then accelerates up to the pre-set desired speed.

Deceleration of the vehicle may take place via intervention in the engine management system. If deceleration via engine torque is not sufficient, brake intervention takes place, braking the vehicle to a standstill if the traffic situation necessitates in vehicles equipped with an automatic transmission. ACC can be reactivated automatically by depressing the accelerator pedal.

In the R-Line and GTI model grades, the dynamics of the ACC system can by individually varied by selecting one of the driving programs from the driving profile selection.

Adaptive Cruise Control (ACC) cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain.

#### Anti-lock Braking System (ABS)

When braking, wheel speed sensors measure the road wheel speed and should one or more wheels start to lock the ABS system reduces brake pressure to that wheel. This prevents the wheels from locking during heavy or emergency braking, enabling the vehicle to remain steerable.

#### Anti-Slip Regulation (ASR)

ASR is a traction control system that prevents the wheels from spinning under acceleration by reducing engine torque.

#### Auto Hold function<sup>^</sup>

As soon as the vehicle comes to a complete stop, the ABS hydraulic unit stores the vehicles final braking pressure. So even when you take your foot off the brake pedal, all four wheels brakes remain applied, providing increased comfort in stationary traffic. This function is released automatically when you drive off again.

#### **Brake Assist**

During emergency braking, Brake Assist aids the driver by increasing the brake pressure automatically to a level exceeding the locking limit. The ABS is thus quickly brought into the operating range, which enables maximum vehicle deceleration to be achieved.

#### **Driving Profile Selection**<sup>^</sup>

Driving profile selection provides the driver with a wide-ranging choice of settings that can be made to the vehicle according to the driver's preferences. The driver has the option of choosing between the following driving profiles: Eco, Comfort, Sport and Individual. Eco mode has been designed to enhance fuel efficiency by adapting engine performance, earlier gearshift points and consumption-optimised control of the air conditioning system. The Comfort profile offers a comfortable but dynamic driving style, with a softer suspension setting of the adaptive chassis control (GTI). Sport provides faster response of the accelerator pedal and steering while the DSG transmission switches to Sport mode. The Individual setting allows the driver to separately set various parameters including steering, engine, Adaptive Cruise Control (ACC) and air conditioning.

#### **Electronic Brake-pressure Distribution (EBD)**

Electronic, more sophisticated means of regulating the ratio of front/rear brake pressure. Settings are varied according to driving and load conditions to ensure each wheel is braked to the optimum extent.

#### **Electronic Differential Lock (EDL)**

EDL improves driving and steering characteristics when accelerating on road surfaces where each wheel has a different degree of traction. The system operates automatically and is combined with the ABS system. Using the ABS wheel sensors, EDL monitors the speed of the individual driving wheels. When a difference in driving wheel speed is detected (i.e. when one wheel starts to spin due to differences in road surfaces, e.g. due to water or dirt) the system brakes the spinning wheel, transferring engine power to the wheel with the best traction.

#### **Electronic Stabilisation Program (ESP)**

ABS and ASR traction control systems are integrated into the Electronic Stabilisation Program (ESP). In short, ESP helps ensure that the vehicle goes where you steer it even in extreme driving conditions. The ESP system constantly compares the actual movement of the vehicle with pre-determined values and should a situation arise where the vehicle starts to skid, ESP will apply the brakes to individual wheels and automatically adjust the engine's power output to correct the problem. ESP prevents the vehicle from losing control when trying to avoid an accident, for example. It also reduces the effects of understeer or oversteer.

#### Emergency Assist<sup>^</sup>

Emergency Assist monitors the driving characteristics and recognises, within the limits of the system, if the driver suddenly becomes incapable of driving (due to the vehicle not being controlled).

Emergency Assist detects a lack of activity on the part of the driver and issues repeated visual and acoustic warnings and initiates a quick jolt of the brakes and tensioning of the driver's seatbelt to request the driver to take control of the vehicle.

If the driver remains inactive, the system automatically controls acceleration, braking and steering to slow the vehicle down and keep it in the lane. If there is sufficient stopping distance, the system decelerates the vehicle to a complete stop and switches on the electronic parking brake automatically, parking position is engaged, the doors are unlocked and the interior lighting switched on.

When Emergency Assist is actively controlling the vehicle, the hazard warning lights are switched on and the vehicle horn may sound to warn other road users. Ideally this will prevent a collision, or at least reduce its severity.

Emergency Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Emergency Assist utilises both the Adaptive Cruise Control (ACC) and Lane Assist driver assistance systems. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

#### Exit Warning System<sup>^</sup>

While the Golf is stationary, the exit warning system warns the occupants about a potential collision when a door is opened. The system uses the rear radar sensors to monitor the area behind and to the side of the vehicle. Where possible, it detects objects, such as cars and cyclists, as they approach the vehicle from behind. When you open the door, the warning lamp on the exterior mirror flashes if another road user in a critical situation is detected. At the same time an acoustic warning signal is heard. The corresponding warning lamps also flash if another road user is detected in a critical situation while the door is already open.

Exit warning system cannot replace the driver's attentiveness. If the driver or passenger notices a risk that pedestrians, other vehicles or objects could be damaged or if they are uncertain of the risk, they will need to react accordingly.

## **Glossary**

#### Extended Electronic Differential Lock (XDL)

XDL is an extension of the Electronic Differential Lock (EDL) function. When cornering, XDL responds to the load relief at the front wheel on the inside of a corner. The ESP hydraulics are used for the XDL to apply pressure to the wheel on the inside of the corner in order to prevent wheel spin. This improves traction and reduces the tendency to understeer. As a direct result of the one-sided and precise braking pressure, cornering is sportier and more accurate.

#### **Fatigue Detection**

The driver Fatigue Detection system automatically analyses the driving characteristics and if they indicate possible fatigue, recommends that the driver takes a break. The system continually evaluates steering wheel movements along with other signals in the vehicle on motorways and others roads at speeds in excess of 60 km/h, and calculates a fatigue estimate. If fatigue is detected, the driver is warned by information in the Multi-function Display and an acoustic signal. The warning may be repeated once if the driver has not taken a break.

Fatigue Detection cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and therefore determining whether or not they are fit to drive. The driving behaviour can be evaluated only when the speed is above approximately 60km/h. The functionality of the system is restricted given a sporty driving style, winding roads and poor road surfaces.

#### Front Assist with Pedestrian and Cyclist Monitoring functions

The Front Assist ambient traffic monitoring system uses a radar sensor and multi-function camera to detect critical distance situations and thus help to shorten the braking distance, reducing the risk of a rear-end collision.

If a vehicle is detected ahead of you in the lane, the distance and the speed relative to it are calculated. If the gap is closing too fast, Front Assist initially warns the driver by means of an audible as well as a visual signal. At the same time, the brake pads are brought into contact with the brake discs and the sensitivity of the Brake Assist is increased. This primes the braking system for a possible emergency stop. Furthermore, an automatic jolt of the brakes warns the driver of the danger. If the driver also fails to react to the warning jolt, Front Assist brakes automatically, helping to avoid a collision or reduce the severity of the accident.

At vehicle speeds below 30km/h, the system monitors the area ahead of the car for vehicles which might present a threat of collision. If a collision is likely, the brakes are first pre-charged and makes the Brake Assist system is made more sensitive: if the driver should notice the risk, the car is ready to respond more quickly to their braking action. However, if the driver still takes no action and a collision becomes imminent, emergency braking is independently applied. If the driver intervenes to try to avoid the accident, either by accelerating hard or by steering, the system will deactivate and allow the driver to complete the avoidance manoeuvre.

Pedestrian and Cyclist Monitoring is an extension of the Front Assist monitoring system. The system uses a radar sensor in the radiator grille and windscreen mounted multi-function camera to monitor the area in front of the vehicle and within the limits of the system, register certain situations, for example a pedestrian stepping onto the road suddenly. The system then gives an immediate acoustic and visual signal to warn the driver. If the driver does not brake, the system initiates a jolt of the brake as a warning about the critical situation, while at the same time preparing for hard braking. If the driver fails to react, the system automatically performs emergency braking, within system limits. Ideally this will prevent a collision, or at least reduce its severity.

Front Assist with Pedestrian and Cyclist Monitoring cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles.

#### Front Differential Lock<sup>^</sup>

The front differential lock is an electronically controlled mechanical differential lock. The drive torque is distributed via an electronically operated clutch in accordance with the driving situation. The differential lock

actively counteracts understeer when cornering by increasing the drive force to the wheel on the outside of the bend. This provides more agility and precision on curves, and a more linear driving response. The front differential lock also provides maximum traction for front-wheel drive vehicles.

Both the XDL and front differential lock increase agility, traction and cornering ability. XDL exerts its effect during medium lateral acceleration, whilst the front differential lock enhances this effect right up to the dynamic driving limit range.

#### Lane Assist

Lane Assist is a lane departure warning system that is designed to help reduce the likelihood of the vehicle leaving the road or crossing into on oncoming lane and therefore the risk of accident as a result of driver distraction or a lapse in concentration.

The Lane Assist system monitors the road ahead with the aid of a camera (located near the interior rear-view mirror) which recognises lane markings and evaluates the position of the vehicle at speeds above 60km/h. If the vehicle starts to leave the lane, the Lane Assist system takes corrective steering action. If this is not sufficient the driver is warned about the situation by a steering vibration. Additionally, if no active steering movements by the driver are recognised, a message will appear in the Digital Cockpit in conjunction with a warning tone. The corrective steering function can be overridden by the driver at any time and the system does not react if the turn indicator is set before crossing a lane marking.

Lane Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and therefore staying in the lane at all times. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

#### Light Assist<sup>^</sup>

Light Assist provides enhanced comfort and safety on the road by means of automatic high beam control. A camera on the interior mirror observes the traffic above 60 km/h and in complete darkness, Light Assist automatically switches on the high beam headlights. The system detects vehicles travelling ahead, as well as oncoming traffic and automatically dips the headlights before they are dazzled. Automatic alternation between high beam and low beam headlights ensures optimum illumination of the road ahead.

#### Manoeuvre braking

Manoeuvre braking assists the driver to avoid or reduce damage in a potential collision by initiating emergency braking. It supports the driver during forward and reverse manoeuvring in a speed range of a maximum 10 km/h. If the risk for an accident is recognised by the parking distance sensors, emergency braking is initiated to minimise possible damage.

Manoeuvre braking cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle. The object must be detected by the sensors. If the driver notices a risk that pedestrians, other vehicles or objects could be damaged they need to react accordingly and stop the vehicle.

#### Multi-collision brake

The multi-collision brake has been designed to provide effective assistance for the driver in the moments after an accident. Multi-collision brake triggers automatic controlled braking once an initial collision has been detected so as to reduce the intensity of further accidents after a collision and can help prevent follow-on collisions with oncoming traffic.

The triggering of the multi-collision brake is based on a collision being detected by the airbag sensors. The ESP control unit limits the deceleration of the vehicle by the multi-collision brake to a defined value and vehicle speed. The vehicle can still be controlled by the driver, even when automatic braking is taking place. The driver can interrupt the multi-collision braking at any time by accelerating or braking even more strongly.

^Only on selected models. Glossary | 16

## **Glossary**

#### Oncoming vehicle braking when turning

Oncoming vehicle braking when turning aims to prevent or reduce the impact of head-on collisions with vehicles when turning. The front radar sensor and windscreen camera are used to monitor the area in front of the driver's own vehicle. If a hazardous situation is detected – the driver turns into oncoming traffic, the vehicle is automatically braked and a warning issued to help prevent a collision.

Key variables for detection of the turning manoeuvre are the steering angle and the steering-angle speed. A turning manoeuvre is detected even if the turn signal has not been activated. The function is active up to a speed of approximately 15 km/h.

Oncoming vehicle braking when turning cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles.

#### **Park Assist**

The third generation Park Assist system actively helps the driver when entering or reversing into 90° parking bays, as well as reversing into and driving out of parallel parking spaces. The system works by using sensors mounted either side of the front and rear bumpers together with parking distance sensors front and rear. To park, the driver simply presses the Park Assist button to select the type of parking manoeuvre and uses the appropriate indicator as the car slowly passes the potential parking space. Sensors scan the size of the parking space as the car is driven past and the driver is alerted if the parking space is big enough. If there is sufficient space, the driver stops the car, selects the correct gear and lets go of the steering wheel.

Park Assist will alert the driver of the intended path and subsequently the appearance of obstacles in the Multi-Function Display, within the driver's field of vision. Park Assist then actively supports the driver by taking over the steering control and parks the vehicle in the available space using the ideal course, if necessary with several moves. The driver can however take over the control of the steering at any time and end the automatic parking procedure.

Park Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle. If the driver notices a risk that pedestrians, other vehicles or objects could be damaged or if they are uncertain of the risk, they will need to react accordingly and stop the vehicle, ending the function.

#### Proactive occupant protection system

The proactive occupant protection system incorporates active and passive safety elements. When the system detects a potential accident situation at speeds above approximately 30km/h, the occupants and the vehicle are prepared for a possible accident. Automatic reversible tensioning of the seat belts secures the driver and front passenger in their seats to attain the best possible protective potential of the airbag and belt system. The hazard warning lights are activated. In case of high transverse dynamics the side windows (and optional panoramic sunroof) are also closed, leaving just a small air gap. Closing of the windows offers optimal support to the head and side airbags which results in the best possible protection.

The latest generation of the Proactive Occupant Protection System can detect risks at the rear utilising the signals from the rear radar sensors for the Side Assist system. If the system recognises an immediate risk, the vehicle and occupants are prepared for a possible rear end collision by warning an approaching vehicle with fast hazard warning light frequency, closing the side windows (and optional panoramic sunroof), as well as tighten the front seat belts.

#### Side Assist with Rear Traffic Alert

Side Assist with Rear Traffic Alert system supports the driver in assessing and avoiding dangerous situations, especially in critical situations, e.g. city and heavy traffic. Side Assist detects cars and motorcycles next to and up to 70m to the right and left behind your own vehicle and highlights these vehicles via a LED indicator in the door mirror at speeds above 15km/h. If you indicate to change lanes, the system calculates whether one of them could be dangerous due to position and speed and if deemed necessary will draw attention to

this by flashing noticeably. In this instance, Lane Assist can also apply corrective steering to help avoid a collision.

Rear Traffic Alert monitors the traffic crossing behind the vehicle when reversing out of a parking space or manoeuvring. Utilising the Side Assist radar sensors in the rear bumper the system warns the driver of approaching traffic via an audible warning followed by a visual message in the Optical Parking System (OPS) and can also provide braking intervention if necessary to help avoid a collision.

Side Assist with Rear Traffic Alert cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles..

#### Traffic Jam Assist<sup>^</sup>

In congested traffic situations, Traffic Jam Assist makes driving significantly more comfortable and helps to avoid typical rear-end collision accidents. The Traffic Jam Assist function combines the driver assistance systems Adaptive Cruise Control (ACC) and Lane Assist with adaptive lane guidance. In a speed range of 0-60km/h, the system automatically controls acceleration, braking, steering and if required, will decelerate to a stop behind a vehicle that is stopping.

Traffic Jam Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Traffic Jam Assist has been developed for use only on motorways. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

#### **Travel Assist**

Travel Assist is an assistance system for partly automated driving. At the push of a button, Travel Assist can support the driver in monotonous and tiring driving situations commonly encountered on long motorway journeys. This system combines the functions of Adaptive Cruise Control (ACC) and Lane Assist with adaptive lane guidance to accelerate, brake and maintain the vehicles position within its lane. The capacitive steering wheel can detect whether the driver's hands are on the steering wheel in readiness to steer the vehicle and will issue a visual and audible warning when not detected.

Travel Assist cannot replace the driver's attentiveness. The driver is still legally responsible for the vehicle and must monitor the speed and distance in relation to other vehicles. Travel Assist has been developed for use only on motorways. The ACC system should not be used on winding roads or in adverse weather conditions such as heavy rain. The system will not work if there are no recognisable lane markings. The camera vision can be reduced by rain, snow, heavy spray or oncoming lights. This and vehicles in front of you can lead to the lane markings not being recognised by the Lane Assist system.

^Only on selected models. Glossary 17

# **Golf Range**

Volkswagen Group Australia Pty Ltd 895 South Dowling Street, Zetland NSW 2017 ABN 14 093 117 876

Printed in Australia
July 2022
Publication: VWPGOLPRANSPMY23

#### Important Information

Apple CarPlay® is a registered trademarks of Apple Inc. Android Auto™ is a registered trademark of Google Inc. Bluetooth® is a registered trademark of Bluetooth SIG Inc.

Volkswagen is distributed by Volkswagen Group Australia Pty Ltd, 895 South Dowling Street, Zetland NSW 2017. ABN 14 093 117 876. Specifications are as planned at July 2022, for Model Year 2023 and are subject to change without notice or obligation. All information is this specification sheet is correct at the time of publication, however variations may occur from time to time and Volkswagen, in so far as it is permitted by law to do so, shall not be liable in any way as a result of any reliance by any person on anything contained in this specification sheet. Authorised Volkswagen dealers will provide up-to-date information on model application, design feature, prices and availability on request.